

INSTALLATION INSTRUCTIONS for your new “EARS” Emergency Alert and Response System

- _____ Decide which working phone jack you want to use.
- _____ Locate electrical outlet (**not controlled by switch**).

Note: When working with unit, be careful not to hit big emergency button on front of unit. (if so press clear button)

TO INSTALL YOUR EARS:

STEP #1 PLUG YOUR EARS INTO ELECTRICAL OUTLET.

STEP #2 PLUG ONE END OF TELEPHONE CORD (SUPPLIED) INTO BOTTOM OF YOUR EARS WHERE IT SAYS “**LINE**” AND THE OTHER END OF THE TELEPHONE LINE INTO YOUR TELEPHONE WALL JACK.

STEP #3 (OPTIONAL) YOU MAY PLUG YOUR REGULAR TELEPHONE INTO THE “PHONE” JACK ON THE BOTTOM OF YOUR EARS AS WELL but **NO OTHER DEVICES MAY BE CONNECTED TO WALL JACK OR EARS FOR IT TO WORK PROPERLY.**

STEP #4 TURN “ON” SWITCH (NEXT TO LINE & PHONE) ON !

YOU ARE NOW READY TO TEST THE MACHINE!

- _____ Push the portable emergency button and wait for your EARS to signal our Monitor to talk to you. It will say “EMERGENCY” for 15 to 20 seconds then “EMERGENCY REPORTED” JUST WAIT! Our monitor will ask you “is everything OK? Make certain they can also hear you AND PLEASE TELL THEM “I’m ok ... just testing”. Operator should confirm client name.
- _____ Keep your packaging box for returning unit. If you need to return unit, call Personal Response office at 1-866-998-6824 to notify us and receive a Return Authorization (RA) number.